

RO SHAM BEAUX

ASSEMBLY INSTRUCTIONS

ORBIT 24 / 30

We recommend installation by a licensed electrician, especially if:

- You're generally not experienced with DIY Projects
- You're installing a chandelier in an area with no existing light fixture or chandelier
- The wiring in your home is old and requires updating
- The chandelier is too heavy or large to handle safely
- You are unsure whether your chandelier will require additional support

PARTS



A. Mounting
Canopy and
Chain



B. Light Cluster



TOP IS
SHORTER END

BOTTOM IS
LONGER END

C. Pull Up Rod



D.
Basket



E. Tassel (or
ball)

ASSEMBLY

1. Disconnect power and mount Canopy (A) to the ceiling.
2. Chain length should be determined prior to installation. Do not adjust chain height with fixture attached. Pull ends of chain link to open - **DO NOT TWIST**.
3. Attach chain to canopy hook. Attach chain to basket (D).
4. Attach lighting cluster (B) to top of basket (D) and thread electrical. (Ground Wire= Small Tin Uncoated Wire / Positive Wire = Grey Coated Wire)
5. Attach top of Pull Up Rod (C) to Bottom of Light Cluster (B) using the shorter end.
6. Lift small hemp wrapped wheel at bottom of basket (D) threading over bottom of pull up rod (C).
7. While holding the wheel in place, attach Tassel (E) to the bottom threads of Pull Up Rod (C). This should secure the bottom of basket (D) to Pull Up Rod (C), allowing it to "buckle".

*Contact customerservice@ro-sham-beaux.com for installation support (843) 789.3478 ext. 309**